

RANGEWOOD EXTRA - Grooved Panel - Installation Details

Notes:

1. Breather membrane must be installed before battening
2. Airflow must be allowed top and bottom – advisable to use Flymesh
3. Battens to brickwork 32x50mm (1 ¼” x 2”), treated
4. Battens to timber frame 25x50mm (1” x 2”), treated
5. Structural Timber frame add suitable sheathing ply to support batten centres of 407mm
6. Batten nominal centres for Grooved Panel maximum 407mm
7. Batten layout to allow for airflow around windows
8. Screw face-fix using Vulcan colour matched stainless steel countersunk screws.
9. Caulking, colour matched apply thin bead between sheets at interlocking edge.