

Notes:

1. Breather membrane must be installed before battening
2. Airflow must be allowed top and bottom – advisable to use Flymesh
3. Battens to brickwork 32x50mm (1 ¼” x 2”), treated
4. Battens to timber frame 25x50mm (1” x 2”), treated
5. Structural Timber frame add suitable sheathing ply to support batten centres of 407mm (16”)
6. Batten nominal centres for Shiplap maximum 407mm
7. Batten layout to allow for airflow around windows
8. Nail using 40mm stainless ringshank – nail must have large flat head
9. Caulking to fill all joints